

# 3-Phase Slim Power Controllers

## SPR3 Series INSTRUCTION MANUAL

TCD210147AD

**Autonics**

Thank you for choosing our Autonics product.

**Read and understand the instruction manual and manual thoroughly before using the product.**

**For your safety, read and follow the below safety considerations before using.**

**For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.**

Keep this instruction manual in a place where you can find easily.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

Follow Autonics website for the latest information.

### Safety Considerations

- Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.
- △ symbol indicates caution due to special circumstances in which hazards may occur.

### Warning

Failure to follow instructions may result in serious injury or death.

**01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime / disaster prevention devices, etc.)**

Failure to follow this instruction may result in personal injury, economic loss or fire.

**02. Do not use the unit in the place where flammable / explosive / corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact or salinity may be present.**

Failure to follow this instruction may result in explosion or fire.

**03. Install on the device panel, and ground to the bolt for grounding separately.**

Failure to follow this instruction may result in fire or electric shock.

**04. Do not connect, repair, or inspect the unit while connected to a power source.**

Failure to follow this instruction may result in fire or electric shock.

**05. Check 'Connections' before wiring.**

Failure to follow this instruction may result in fire.

**06. Do not disassemble or modify the unit.**

Failure to follow this instruction may result in fire or electric shock.

### Caution

Failure to follow instructions may result in injury or product damage.

**01. Use the unit within the rated specifications.**

Failure to follow this instruction may result in fire or product damage.

**02. Use a dry cloth to clean the unit, and do not use water or organic solvent.**

Failure to follow this instruction may result in fire or electric shock.

**03. Keep the product away from metal chip, dust, and wire residue which flow into the unit.**

Failure to follow this instruction may result in fire or product damage.

**04. Since leakage current still flows right after turning off the power or in the output OFF status, do not touch the load terminal.**

Failure to follow this instruction may result in electric shock.

### Cautions during Use

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- Use the product, after 3 sec of supplying power.

Before use, set the mode and function according to the specification. Especially, be cautious that the product does not operate when output control adjuster (OUT ADJ) is set to 0 %. Since changing the mode / parameter during operation may result in malfunction, set the mode and function after disconnecting load output.

Re-supply the power to the unit after the unit is discharged completely. Failure to follow this instruction may result in malfunction.

To ensure the reliability of the product, install the product on the panel or metal surface vertically to the ground.

Install the unit in the well ventilated place.

While supplying power to the load or right after turning off the power of the load, do not touch the body and heat sink. Failure to follow this instruction may result in a burn due to the high temperature.

Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.

Do not wire to terminals which are not used.

Use twisted pair wire for communication line.

Since inter element can be damaged when using with coil load, inductive load, etc., the inrush current must be under the rated load current.

Do not use near the equipment which generates strong magnetic force or high frequency noise.

This unit may be used in the following environments.

- Indoors (in the environment condition rated in 'Specifications')

- Altitude max. 2,000 m

- Pollution degree 2

- Installation category III

### Ordering Information

This is only for reference, the actual product does not support all combinations. For selecting the specified model, follow the Autonics website.

**SPR 3 - ① ② ③ ④ ⑤**

#### ① Rated load voltage

1: 110 VAC~  
2: 220 VAC~  
3: 380 VAC~  
4: 440 VAC~

#### ② Rated load current

Number: Rated load current (unit: A)

#### ③ Option output

N: Alarm output  
T: Alarm output + RS485 comm. output

### Product Components

- Product
- Instruction manual
- 11-pin connector X 1
- Insulating barrier X 4

### Manual

For proper use of the product, refer to the manuals and be sure to follow the safety considerations in the manuals.

Download the manuals from the Autonics website.

### Software

Download the installation file and the manuals from the Autonics website.


#### ■ DAQMaster

It is the comprehensive device management program for Autonics' products, providing parameter setting, monitoring and data management.


### Dimensions

• Unit: mm, For the detailed drawings, follow the Autonics website.


#### ■ Rated load current 25 / 35 / 50 A



#### ■ Rated load current 70 A



#### ■ Rated load current 100 / 150 A




### Insulating Barrier

It is recommended to use the included interphase barriers for insulation between phases and reduce influence from conductive material.

- Unit: mm, For the detailed drawings, follow the Autonics website.

#### With the insulating barrier



### Specifications

Model	SPR3-1	SPR3-2	SPR3-3	SPR3-4
Control phase	3-Phase			
Rated load voltage	110 VAC~ 50 / 60 Hz	220 VAC~ 50 / 60 Hz	380 VAC~ 50 / 60 Hz	440 VAC~ 50 / 60 Hz
Rated load current	25 / 35 / 50 / 70 / 100 / 150 A			
Display method	3-digit 7segment LED			
Indicators	Operation / manual control indicator (green) Alarm / output / unit (V, A) indicator (red)			
Auto control input	Current: DC 4 - 20 mA, voltage: 1 - 5 VDC=, contact (non-voltage): ON / OFF, contact (voltage): 5 - 12 VDC=, communication: RS485			
Manual control input	External adjuster (10 kΩ), output control adjuster (OUT ADJ)			
Digital input (DI)	RUN / STOP selectable, AUTO / MAN selectable, RESET			
Alarm output	250 VAC~ 3 A, 30 VDC= 3 A, 1c resistance load			
RS485 comm. output	Modbus RTU method			
Cooling method	Rated load current 25 / 35 / 50 A: natural cooling Rated load current 70 / 100 / 150 A: forced air cooling (with cooling fan)			
Unit weight (packaged)	Rated load current 25 / 35 / 50 A: ≈ 4.1 kg (≈ 4.9 kg) Rated load current 70 A: ≈ 4.2 kg (≈ 5 kg) Rated load current 100 / 150 A: ≈ 8.7 kg (≈ 9.7 kg)			
Approval	CE			
Control method	Phase control	Cycle control	ON/OFF control	
Control mode	Normal / constant current feedback / constant voltage feedback / constant power feedback	Fixed cycle	-	
Applied load	Resistance load, inductive load	Resistance load	Inductive load	
Output range	0 to 98 %	0 to 100 %	0 / 100 %	
Phase control output accuracy	• Normal control: within ± 10 % F.S. of rated load voltage • Constant current feedback control: within ± 3 % F.S. of rated load current • Constant voltage feedback control: within ± 3 % F.S. of rated load voltage • Constant power feedback control: within ± 3 % F.S. of rated load power			
Power supply	100 - 240 VAC~ ± 10 % 50 / 60 Hz			
Min. load current	1 A			
Power consumption	Rated load current 25 / 35 / 50 A: ≤ 14 VA Rated load current 70 A: ≤ 22 VA Rated load current 100 / 150 A: ≤ 32 VA			
Insulation resistance	≥ 200 MΩ (500 VDC= megger)			
Dielectric strength	Between input and power terminal: 2,000 VAC~ 50 / 60 Hz for 1 min			
Output leakage currents	≤ 10 mA rms			
Noise immunity	± 2 kV square wave noise (pulse width: 1 μs) by the noise simulator			
Memory retention	≈ 10 years (when using non-volatile semiconductor memory type)			
Vibration	0.75 mm double amplitude at frequency of 5 to 55 Hz (for 1 min) in each X, Y, Z direction for 2 hours			
Vibration (malfunction)	0.5 mm double amplitude at frequency of 5 to 55 Hz (for 1 min) in each X, Y, Z direction for 10 min			
Ambient temp.	-10 to 55 °C, storage: -20 to 80 °C (no freezing or condensation)			
Ambient humi.	35 to 85 %RH, storage: 35 to 85 %RH (no freezing or condensation)			

### Cautions during Installation

#### High Temperature Caution


While supplying power to the load or right after turning off the power of the load, do not touch the body and heatsink.

Failure to follow this instruction may result in a burn due to the high temperature.

#### Mount space


- Unit: mm

When installing multiple power controllers, keep space between power controllers for heat radiation.  
Horizontal: ≥ 50 mm, vertical: ≥ 100 mm




### Derating Curve


#### ■ Rated load current 25 A



#### ■ Rated load current 35 A



## Unit Descriptions



01. Bracket [except rated load current 100 / 150 A model]

02. Indicator

Indicator	Function
RUN	Operation indicator (green)
MAN	Manual control indicator (green)
ALM	Alarm indicator (red)
OUT	Output indicator (red)

03. Display part

RUN mode: Displays depending the front display setting

Setting mode: Displays parameter and setting value

04. Unit indicator (V, A)

Dependent on the display setting.

Display setting	V	A
Resistance and input	OFF	OFF
Voltage	ON	OFF
Current	OFF	ON
Power	ON	ON


05. [MODE] key  
Enters parameter group, returns to RUN mode, moves parameters, and saves the setting value.

06. [ $\blacktriangleleft$ ,  $\triangleright$ ,  $\blacktriangledown$ ,  $\blacktriangleup$ ] key  
Enters SV setting mode and move digits.

## Cautions during Wiring

### Control input / comm. output terminal (11-pin connector)

• Unit: mm, Use penhole terminals of size specified below.



### Alarm output / power input & U, V, W load output terminal

• Unit: mm, Use crimp terminals of size specified below.

Rated load current	Spec.	Alarm output / power input	Load input / output
25 / 35 / 50 / 70 A	a	$\geq 3.0$	$\geq 6.0$
	b	$\leq 6.0$	$\leq 16.0$
100 / 150 A	a	$\geq 3.0$	$\geq 8.0$
	b	$\leq 6.0$	$\leq 26.0$


• Cable / screw / tightening torque spec. is different depending on the load current. Be sure to the below before connection.

Rated load current	Spec.	Alarm output / power input	Load input / output
25 / 35 / 50 / 70 A	Cable	AWG 18 to 14	AWG 13 to 4
	Screw	M3	M6
	Tightening torque	0.5 N m	5.5 to 6.0 N m
100 / 150 A	Cable	AWG 18 to 14	AWG 4 to 2 / 0
	Screw	M3	M8
	Tightening torque	0.5 N m	6.5 to 7.0 N m


## Connections

• Terminal configuration by model may differ depending on the supported spec.


### Control input / comm. output terminal (11-pin connector)



### Load input / output terminal (11-pin connector)



### Alarm output / power input terminal



## Alarm

• Supported alarms are different depending on the model.

• When several alarms occur at same time, the highest priority error is displayed based on priority.

Priority	Type	Display	Operation	Alarm release	Model
1	SCR error	5Cr			Feedback control
2	Over current	o - C			Feedback control
4	Heatsink over heat	tEñ	• Error display flashes.	Output stops. (SCR OFF)	Normal / Feedback control
5	Over voltage	o - u	• Alarm indicator (ALM) flashes.	• Re-supply power.	Normal / Feedback control
7	Load unbalance	UL	• Alarm output turns ON	• RESET input	Feedback control
3	Fuse break	FUS		• Switch to stop (STOP) mode.	
8	Frequency error	Frq			
6	Heater break	H - b			

#### SCR error alarm

Even though output is 0 %, if the current of 10 % or more of the rated load current flows for over 3 sec continuously, SCR error alarm occurs.

#### Over current alarm

This function protects the load from over current. If the current flows over the P2-7 over current alarm value and P2-8 over current alarm delay time, over current alarm occurs.

#### Heatsink over heat alarm

When the temperature of a heatsink is over 85 °C, heatsink over heat alarm occurs.

#### Over voltage alarm

This function protects the load from over voltage. If the current flows over the P2-9 over voltage alarm value and P2-10 over voltage alarm delay time, over voltage alarm occurs.

#### Load unbalance alarm

If the current of U, V, W is  $[load\ unbalance\ value \geq P2-13\ load\ unbalance\ alarm\ value]$ , the alarm occurs.

When the alarm occurs, the load output operates as according to the set of P2-14 output when load unbalance alarm occurs.

→ ON: normal operation, OFF: output stops (SCR OFF)

Load unbalance value ( $A = I_{max} - I_{min}$ ) ( $I_{max}$ : maximum phase load current value,  $I_{min}$ : minimum phase load current value)

E.g.) R phase: 7 A, S phase: 2 A, T phase: 3 A, P2-13 load unbalance alarm value: 2 A

Load unbalance value  $= 7 - 2 = 5$  A

Load unbalance value  $> P2-13$  load unbalance alarm value and the alarm occurs.

#### Fuse break alarm

When breaking fuse, not supplying load power, breaking load (single load), fuse brake alarm occurs. In the case of normal control model, real-time fuse break alarm is not available during output, and fuse break alarm operates at 0 % output such as RESET.

#### Heater break alarm

Comparing the full load resistance value and the current load resistance value, if the current load resistivity is maintained under the P2-12 heater break alarm value for over 3 sec continuously, heater break alarm occurs. This alarm operates when control output is over 10 % and load current is over 10 % of the rated current. Output does not stop and operates normally.


Current load resistance (%) =  $\frac{\text{Full load resistance value} \times 100}{\text{Current load resistance value}}$

#### Frequency error alarm

When the load power frequency is out of the specification, frequency error alarm occurs.

## Replacement of Fuse

### Case removal



### Replacement of fuse

• Fuse none model is not equipped with a rapid fuse inside. Install the suitable fuse for rated load current of the model separately.


• The performance of the product is guaranteed only when using the fuse provided by us. For replacing the fuse, use the recommended fuse.

Rated load current	Rec. fuse	Manufacturer
25 A	50FE	BUSSMANN
35 A	63ET	
50 A	80ET	
70 A	100FE	
100 A	660GH-160	HINODE
150 A	660GH-200	

### Bolt specification

Rated load current	Case fixed bolt	Fuse fixed bolt
25 / 35 / 50 / 70 A	M3	M6
100 A	M4	Top: M8 Bottom: M6
150 A	M4	M8

## Mode Setting



01) In the event of system anomalies and alarms, RESET input restarts the power controller. (parameters are not reset.)

## Parameter Setting

• Some parameters are activated / deactivated depending on the model or setting of other parameters. Refer to the description of each parameter.

• If any key is not entered for 30 sec in each parameter, it returns to RUN mode.

• [MODE] key: Saves current setting value and moves to the next parameter.

• [ $\blacktriangleleft$ ,  $\triangleright$ ] key: Changes setting digits.

• [ $\blacktriangleup$ ,  $\blacktriangledown$ ] key: Changes setting values.

### Monitoring group

Parameter	Display	Display range
M1-1 Monitoring value	l - r	0 to 100 %
M1-2 U-V line load voltage value	U - u	[Feedback control model] 0 to rated voltage range, V
M1-3 V-W line load voltage value	u - v	[Feedback control model] 0 to rated voltage range, V
M1-4 W-U line load voltage value	v - u	[Feedback control model] 0 to rated voltage range, V
M1-5 U-phase load current value	U - R	[Feedback control model] 0 to rated current range, A
M1-6 V-phase load current value	U - R	[Feedback control model] 0 to rated current range, A
M1-7 W-phase load current value	U - R	[Feedback control model] 0 to rated current range, A
M1-8 Load power value	U - R	[Feedback control model] 0 to rated Power range, kW
M1-9 Resistance value percentage	l - r	[Feedback control model] 0 to 100 % • Displays the present resistance as percentage compared to